



Dansk (oversat fra original brugsvejledning)	3
Deutsch (Übersetzung der Originalanweisung)	5
English (original instructions)	8
Español (traducido de las instrucciones originales)	10
Français (traduction de la notice d'instructions originale)	13
Italiano (tradotto dalle istruzioni originali)	16
Nederlands (vertaald vanuit de originele instructies)	19
Norsk (oversatt fra de originale instruksjonene)	22
Português (traduzido das instruções originais)	24
Suomi (käännetty alkuperäisestä käyttöohjeesta)	27
Svenska (översatt från de ursprungliga instruktionerna)	29
Türkçe (orijinal talimatlardan çevrilmiştir)	31
Ελληνικά (μετάφραση από τις πρωτότυπες οδηγίες)	33

Fig. A




Fig. B




Fig. C





Fig. D

Fig. D



HEAVY-DUTY TABLE SAW STAND

DWE74912

Congratulations!

You have chosen a DEWALT tool. Years of experience, thorough product development and innovation make DEWALT one of the most reliable partners for professional power tool users.

Technical Data

DWE74912		
Type		TY2
Width (Extended)	mm	980
Width (Folded)	mm	85
Height (Extended)	mm	665
Height (Folded)	mm	1055
Maximum working load	kg	68
Maximum Load	kg	68
Weight	kg	6.8

Definitions: Safety Guidelines

The definitions below describe the level of severity for each signal word. Please read the manual and pay attention to these symbols.



DANGER: Indicates an imminently hazardous situation which, if not avoided, **will** result in **death or serious injury**.



WARNING: Indicates a potentially hazardous situation which, if not avoided, **could** result in **death or serious injury**.



CAUTION: Indicates a potentially hazardous situation which, if not avoided, **may** result in **minor or moderate injury**.

NOTICE: Indicates a practice **not related to personal injury** which, if not avoided, **may** result in **property damage**.

General Safety Warnings



WARNING: Read all safety warnings and all instructions enclosed with the saw stand and the power tool to be mounted. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

General Safety Instructions for Table Saw Accessories



WARNING: To reduce the risk of personal injury:

- Follow the mounting instructions carefully. Fasten the saw to the stand securely as instructed. Proper assembly is important to prevent the risk of a collapse of the saw stand.

- Ensure all stand fasteners are securely fastened and that all stand mechanisms are in proper working order before mounting or operating the table saw. Proper assembly is important to prevent the risk of a collapse of the saw stand.
- Attach the power tool securely to the saw stand before using it. Sliding off of the power tool on the saw stand can lead to loss of control.
- DO NOT use the stand on uneven surfaces. The stand is designed to be used on a flat, stable surface.** If the saw stand can slide around or wobbles, the power tool or the workpiece cannot be evenly and securely guided.
- Pull the plug from the mains receptacle and/or remove the battery from the power tool before making adjustments on the tool or changing tool accessories. Unintentional switching on of the power tool is the cause of many accidents.
- Ensure that long and heavy workpieces do no affect to the balance of the saw stand. Long and/or heavy workpieces must be supported at the free end.
- Keep your fingers clear of the hinge points while folding the legs of the saw stand. Danger of fingers being crushed or contused.

Package Contents

The package contains:

- 1 Table Saw Stand
- 4 8 mm Hex bolts, nuts, and washers
- 4 8 mm Carriage bolts, nuts, and washers
- 1 Instruction manual
- Check for damage to the tool, parts or accessories which may have occurred during transport.
- Take the time to thoroughly read and understand this manual prior to operation.

Markings on Tool

The following pictograms are shown on the tool:



Read instruction manual before use.



DO NOT exceed the weight this stand can hold. The DWE74912 table saw stand is designed to support 68 kg safely in a work environment.



DO NOT climb, sit or stand on the stand.



DO NOT drop heavy loads on the table.

Date Code Position (Fig. B)

The date code **4**, which also includes the year of manufacture, is printed into the housing.

Example:

2018 XX XX

Year of Manufacture

Description (Fig. A)



WARNING: Never modify the power tool or any part of it. Damage or personal injury could result.

Intended Use

This table saw stand is designed for use with DEWALT DWE7491 and DWE7492 table saws. If you have any problem with alignment or mounting, consult an authorised DEWALT repair agent.

DO NOT use under wet conditions or in the presence of flammable liquids or gases.

DO NOT let children come into contact with the tool. Supervision is required when inexperienced operators use this tool.

- **Young children and the infirm.** This appliance is not intended for use by young children or infirm persons without supervision.
- This product is not intended for use by persons (including children) suffering from diminished physical, sensory or mental abilities; lack of experience, knowledge or skills unless they are supervised by a person responsible for their safety. Children should never be left alone with this product.

ASSEMBLY AND ADJUSTMENTS



WARNING: To reduce the risk of serious personal injury, turn tool off and disconnect from power source before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.

- Assemble as shown in Figure A using hex bolts, nuts, and washers; all leg pieces are equal lengths.

Tools Required for Assembly

- 2 13 mm wrenches

To Open Table Saw Stand (Fig. B–D)

1. Unfold the saw stand until it is fully opened. Place it upright, as shown in Figure B.
2. Place the table saw on the stand by sliding the front tube **1** of the saw into the lip **2** on the front of the stand (Fig. C).
3. Lower the rear feet of the saw onto the rear rail **3** at the back of the stand as shown in Figure C.
4. Secure the front and rear of the saw with the 4 carriage bolts provided (Fig. D). Install bolts FROM THE BOTTOM. Install washers and nuts on the top. Tighten securely. Be sure the saw does not rock or wobble in place.

To Close the Stand



Disconnect the saw from power supply before closing the stand. Adjust the saw into transport condition, see manual of the table saw.

1. Remove the 4 carriage bolts that secure saw to the stand.
2. Tilt the rear of the saw up allowing the rear feet to clear the lip on the back of the stand.
3. Pull the saw forward and up allowing the front tube to slide out of the lip on the stand.
4. After stowing the saw, pick the stand up by both rails and close it by squeezing the top rails toward each other.

MAINTENANCE

Your DEWALT power tool has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper tool care and regular cleaning.



WARNING: To reduce the risk of serious personal injury, turn tool off and disconnect from power source before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.



Cleaning



WARNING: Never use solvents or other harsh chemicals for cleaning the non-metallic parts of the tool. These chemicals may weaken the materials used in these parts. Use a cloth dampened only with water and mild soap.

Optional Accessories



WARNING: Since accessories, other than those offered by DEWALT, have not been tested with this product, use of such accessories with this tool could be hazardous. To reduce the risk of injury, only DEWALT recommended accessories should be used with this product.

Consult your dealer for further information on the appropriate accessories.

Protecting the Environment



Separate collection. Products and batteries marked with this symbol must not be disposed of with normal household waste.

Products and batteries contain materials that can be recovered or recycled reducing the demand for raw materials. Please recycle electrical products and batteries according to local provisions. Further information is available at www.2helpU.com

Belgique et Luxembourg Belgie en Luxemburg	DeWALT - Belgium BVBA Egide Walschaertsstraat 16 2800 Mechelen	Tel. NL 32 15 47 37 63 Tel. FR 32 15 47 37 64 Fax 32 15 47 37 99	www.dewalt.be enduser.BE@sbdinc.com
Danmark	DeWALT (Stanley Black&Decker AS) Roskildevej 22 2620 Albertslund	Tel: 70 20 15 10 Fax: 70 22 49 10	www.dewalt.dk kundeservice.dk@sbdinc.com
Deutschland	DeWALT Richard Klinger Str. 11 65510 Idstein	Tel: 06126-21-0 Fax: 06126-21-2770	www.dewalt.de infoDWGE@sbdinc.com
Ελλάς	DeWALT (Ελλάς) Α.Ε. ΕΔΡΑ-ΓΡΑΦΕΙΑ : Στράβωνος 7 & Α. Βουλιαγμένης, Γλυφάδα 166 74, Αθήνα SERVICE : Ημέρος Τοπος 2 (Χάνι Αδών) – 193 00 Ασπρόπυργος	Τηλ: 00302108981616 Φαξ: 00302108983570	www.dewalt.gr Greece.Service@sbdinc.com
España	DeWALT Ibérica, S.C.A. Parc de Negocios "Mas Blau" Edificio Muntadas, c/Bergada, 1, Of. A6 08820 El Prat de Llobregat (Barcelona)	Tel: 934 797 400 Fax: 934 797 419	www.dewalt.es respuesta.postventa@sbdinc.com
France	DeWALT 5, allée des Hêtres BP 60105, 69579 Limonest Cedex	Tel: 04 72 20 39 20 Fax: 04 72 20 39 00	www.dewalt.fr scufr@sbdinc.com
Schweiz Suisse Svizzera	DeWALT In der Luberzen 42 8902 Udorf	Tel: 044 - 755 60 70 Fax: 044 - 730 70 67	www.dewalt.ch service@rotoag.ch
Ireland	DeWALT Building 4500, Kinsale Road Cork Airport Business Park Cork, Ireland	Tel: 00353-2781800 Fax: 01278 1811	www.dewalt.ie Sales.Ireland@sbdinc.com
Italia	DeWALT via Energypark 6 20871 Vimercate (MB), IT	Tel: 800-014353 39 039-9590200 Fax: 39 039-9590311	www.dewalt.it
Nederlands	DeWALT Netherlands BVPostbus 83, 6120 AB BORN	Tel: 31 164 283 063 Fax: 31 164 283 200	www.dewalt.nl
Norge	DeWALT Postboks 4613 0405 Oslo, Norge	Tel: 45 25 13 00 Fax: 45 25 08 00	www.dewalt.no kundeservice.no@sbdinc.com
Österreich	DeWALT Werkzeug Vertriebsges m.b.H Oberlaaerstrasse 248, A-1230 Wien	Tel: 01 - 66116 - 0 Fax: 01 - 66116 - 614	www.dewalt.at service.austria@sbdinc.com
Portugal	DeWALT Ed. D Dinis, Quina da Fonte Rua dos Malhoes 2, 2A 2º Esq. Oeiras e S. Juliao da Barra, paço de Arcos e Caxias 2770 071 Paço de Arcos	Tel: +351 214667500 Fax: +351 214667580	www.dewalt.pt resposta.postvenda@sbdinc.com
Suomi	DeWALT PL47 00521 Helsinki, Suomi	Puh: 010 400 4333 Faksi: 0800 411 340	www.dewalt.fi asiakaspalvelu.fi@sbdinc.com
Sverige	DeWALT BOX 94 43122 Molndal Sverige	Tel: 031 68 61 60 Fax: 031 68 60 08	www.dewalt.se kundservice.se@sbdinc.com
Türkiye	Sanayi ve Ticaret Bakanlığı tebliğince kullanım omru 7 yıldır. Stanley Black & Decker Turkey Alet Üretim San. Tic. Ltd.Şti. Kozyatağı Mh Degirmen Sk. Nida Kule No: 18 Kat: 6, 34742 Kadıköy, İstanbul, Türkiye	Tel: +90 216 665 2900 Faks: +90 216 665 2901	www.dewalt.com.tr info-tr@sbdinc.com
United Kingdom	DeWALT, 210 Bath Road; Slough, Berks SL1 3YD	Tel: 01753-567055 Fax: 01753-572112	www.dewalt.co.uk emeaservice@sbdinc.com
Australia	DeWALT 810 Whitehorse Road Box Hill VIC 3128 Australia	Tel: Aust 1800 338 002 Tel: NZ 0800 339 258	www.dewalt.com.au www.dewalt.co.nz
Middle East Africa	DeWALT P.O. Box - 17164, Jebel Ali Free Zone (South), Dubai, UAE	Tel: 971 4 812 7400 Fax: 971 4 2822765	www.dewalt.ae Service.MEA@sbdinc.com